



Location	Article number	Description	Location	Article number	Description
A1	16040	Grub Screw	F1	17004	Resetaxel
A2	11532	Grub Screw	F2	2637 and 11633	G Screw
A3	11512	Brasscap M8	F3	11508	Grub Screw
A4	14012	Magazine Pin Slider	F4	17060	Resetpin
A5 - 4,5	1704	Magazine 4,5	F5	17040	Resetscrew
A5 - 5,5	1701	Magazine 5,5	F6	17018	Spring
A6-7	2503	Grub Screw	G1	5110	Rubberball
A8	5201	SH Screw	G2	11508	Grub Screw
A9	11526	Recoilpad	G3	5110	Rubberball
A10	2503	SH Screw	G4	17011	Safetyslider
A11	14010	Rear Stock	G5	17012	Safetyhandle
A12	0315	Tube 500cc	H1-2	2637	Grubscrew
A13	14500	SH Screw	H3	11511	CS Screw
A14	14011	Stock grip	H4 - 4,5	17050	Barrelhousing
A15	11502	Pivot Pin	H4 - 5,5	17015	Barrelhousing 5,5
A16	17021	Stock Front Grip	H5	11511	CS Screw
B1 - 4,5	12030	Barrel 4,5	H6 - 4,5	17059	Pelletprobe 4,5
B1 - 5,5	12006	Barrel 5,5	H6 - 5,5	17014	Pelletprobe 5,5
B2	17019	Transferpipe 10x236	H7	11042	Spring guide M5
B3	2503	Grub Screw	H8	17052	Spring
B4-5	2637	Grub Screw	H9	BK40.5	O-ring
B6	17008	Reloading chamber	H10	11642	Poweradjuster
B7	17042	Reloading chamber tube	> H10	4066	Steelball
D1	2534	Grub screw	> H10	11503	Spring
D2 - 5,5	13010	Muzzle thread cover	H11	BK40.5	O-ring
D3 - 4,5	17023	Muzzle 4,5	H12	11514	Pivot Pin
D3 - 5,5	17038	Muzzle 5,5-1/2" UNF	H13	14008	Air Bottle Connector
D4	17009	Expansion Chamber	H14	12033	Grub Screw
D5	4006	L Connection	H15 x2	11506	SH Screw
D6	17039	Hose connection	H16	11505	Manometer
D7	17044	Rubber Hose	H17	5005	Plastic washer 2mm
D8	17037	Hose Cover	H18	17016	Main Body
E1		Piano wire v4	H19	18047	Hammer for Semi-Auto
E2	11525	Trigger Wheel	H20	17003	Hammerweight
E3	11502	Pivot Pin 2x20	H21	16024	Hammerspring
E4	2500	Grubscrew M3x6	H22	17006	Hammerspring adjuster
E5	2527	SH Screw	H23	11508	Grub Screw
E6	17020	Trigger Sear	I1	17010	Cockingbolt mount P1/2
E7	11502	Pivot Pin 2x20	I1	17005	Cockingbolt mount P2/2
E8	17046	1st Stage Spring	I2	4018	Cocking bolt
E9	2500	Grubscrew	I3	2504	CS Screw
E10	11015	2nd stage adjuster	I4	11546	SH Screw
E11	2063	Trigger spacer	J1-2	2500	Grubscrew
E12	2020	Trigger	J3	17013	Cocking bolt catcher
E13	17017	Trigger base			

K1	17001	Piston Seal 12,7	K15	14002	Inlet valve housing
K2	17002	Piston Seal 25,4	K16-17	7045	Inlet valve assembly
K3	17007	Piston	K16	5111	O-ring
K4	14007	Reloading Tube 22	K17	12011	Inlet valve
K5-6	11546	SH Screw	K18	5204	Spring
K7	14009	Fork Clamp	K19	BK40.5	O-ring
K8	14006	Fork	K20	14001	Air reservoir
K9-12	7035	Valvepin assembly	K21	12004	Slider ring
K9	2040	Plastic Valve Seal	K22	BK108	O-ring
K10	2041	Valve Seal Holder	K23	17041	Plastic seal 15x3
K11	BK5	O-ring	K24	14005	Air Cylinder Connector
K12	11011	Valvepin	K25	BK90	O-ring
K13-14	7044	Valveseat assembly	K26-28-30	14022	Transferpipe assembly
K13	2023	Valveseat	K27	BKD12	Rubber/Steel Washer
K14	BK38	O-ring	K31	14015	Plastic seal