


EXP-CR600W



序号	零件名称	数量
1	front sight screw	1
2	front sight	1
3	suppressor insert	1
4	suppressor screw	1
5	elevation screw	1
6	rear sight base	1
7	windage screw	2
8	rear sight	1
9	rear sight base pin	1
10	rear sight block	1
11	rear sight base spring	1
12	air reservoir mount	1
13	air reservoir mounting screw	1
14	barrel	1
15	barrel O ring	2
16	breach O ring	1
17	safety screw	1
18	barrel fixing screw	3
19	insert magnet	1
20	rear sight screw	1
21	breach	1
22	ball	1
23	trigger pin	1
24	piston screw bushing	2
25	piston screw	2
26	valve connector O ring	1
27	valve connector	1
28	valve	1
29	exhaust valve core pin	1
30	exhaust valve core	1
31	exhaust valve core cover	1
32	valve spring	1
33	valve O ring	1
34	valve	1
35	stopper ring	1
36	valve seal pin	1
37	valve seal	1
38	valve seal nut	1
39	locking cover	1
40	air tube assembly	1
41	trigger base	1
42	trigger base screw	1
43	trigger	1
44	trigger screw	1
45	sear	1
46	trigger spring	1
47	trigger pin	3
48	breach lower screw	1
49	piston	1
50	piston spring	1
51	piston rod	1
52	piston cover	1
53	wood stock	1
54	air reservoir mount screw	1

序号	零件名称	数量
55	wood stock screw	1
56	trigger guard screw	1
57	trigger guard	1
58	trigger guard screw	1
59	left safety button	1
60	right safety button	1
61	detent ball	1
62	safety spring	1
63	gas cylinder rod	1

设计 Designed by _____
 审核 Reviewed by _____
 批准 Approved by _____