

spares.bagnallapdkirkwuuu.uu. Spare parts available at: spares.bagnallandkirkwood.co.uk

sparce

For spare parts not listed please contact us using the reference codes above

<i>a</i>			
1	Muzzle Extension	53	Nut Socket
23	Screw	54	Cocking Arm Spring
ha93	Barrel	54 55	Spring Pin
spares.bag3	Sight Base	56	Fastening Screw
sparce 4	Screw	57	Seal Ring
5 <u>6</u>	Pellet Channel Screw	58	Latch Washer
7	Pellet Channel	59	trigger Screw
8	Screw	60	Trigger Lever Spring
29/10	Nut	61	Adjustment Screw, Rear
10	Ball Catch Screw	62	Trigger Guard
coares 11	Ball Catch Spring	63	Trigger Lever
spares 10 11 12	Steel Ball	64	Distance Washer
13	Receiver Body	65	Pin
14	BK25 'O' Ring	66	Trigger Base
. 15	Loading Bolt	67	Screw
C 1677	Screw	68	Trigger base Spring
spare 17 18	Roller Bush	CO 69	Locking Washer
SPC 18	Screw, Loading Bolt	70	Adjustment Screw Front
19	Nut	71	Trigger
20	Bolt Handle	72	Stock Side Screw
21	Bolt Handle Nut	73	5mm Washer
2200	Adjustment Screw	74	Butt Stock
(C-23	Main Spring	75.0	6mm Washer
SP0 24	Main Spring Guide	76	Connecting Screw
25	Striker	77	Screw
26	Roller Bush	78	Roller
27	Screw, Cocking	79	Cheek Piece
28	Washer 4 or 8	80	Adjustable Butt Pad
295	Roller Bush	88	Lock Washer
50 30	Pressure Gauge	89	Latching Nut
31	BK119 'O' Ring, Cylinder	91	Screw
32	Cylinder Tube	92	Screw
33	Pot		
34	Valve Cap	C	Z 200 S Different Parts
35.00	Valve Spring	81	Solid Butt Stock
36	Firing Valve Seat	82	Ventilated Rubber Butt Pad
37	Firing Valve Gate	83	Single Fore-End Stock
38	End Plug, Firing Valve	90	Screw
39	BK63 "o" Ring, Plug	93	Muzzle Extension Sporting
40	Striking Pin		
41	Striking Pin Spring	A	A S 200 Different Parts
42	1.9mm Retaining Pin	81	Solid Butt Stock
543	Supporting Bracket	82	Ventilated Rubber Butt Pad
44	Fore-End Stock	83	Single Fore-End Stock
45	Fore-End Rail	84	Filling Connector
46	Wood Screw	85	Filling Connector End Plug
48	Fore-End Stock Screw	86	Connector Cover
49	Cocking Arm Guide	87	BKD8 Washer
50	Cocking Arm Guide Screw	93	Muzzle Extension Sporting
51	Cocking Arm	KNUU	
52	Pivot, Cocking Arm		

Spare parts available at: spares.bagnallandkirkwood.co.uk

spé

For spare parts not listed please contact us using the reference codes above anallandkin