




A.



B.



C.



Spare parts available at:
spares.bagnallandkirkwood.co.uk

For spare parts not listed please contact us using the reference codes above

Location	Article number	Description	Location	Article number	Description
A1	19690	Trigger Block Impact	B14	19642	Guiding Plate Impact
A2	1501	CPK	B15	2527	MC6S
A3	19638	Cockinglever Impact	B16	19633	Cheekrest Back
A4	19026	CPK 2,5m6x6	B17	19634	Cheekrest Front
A5	19021	Lever Linkage	B18	11506	MC6S
A6	BK98	O-ring	B19	19667	Reloading Bar
A7	19650	Barrel Guiding back	B20	19729	Barrel lock screw
A8	19740	MC6S	B21	19698	Rear block Impact
A9	19652	Delrin Puck 5	B22	19674	O-ring Stop Valvetube
A10	19691	Reloading block Impact	B23	BK23	O-ring
A11	19653	Delrin Puck 5	B24	BK76	O-ring
A12	19601	Hammerpin	B25	19615	Valvetube 20mm
A13	19651	Barrel guiding Front	B26	19603	Valven ut impact
A14	19611	Cockinglever Handle	B27	19217	Valvseat complete
A15	11060	MC6S	B28	7064	Valvepin complete Impact
A16	11599	Rubberbaal	B29	BK82.7	O-ring
A17	19616	Valvestop Impact	B30	19605	Valvehouse
A18	BK69	O-ring	B31	19630	Plate holder impact
A19	19668	Valve adjuster screw	B32	19224	Grubscrew
A20	19669	Valve Ajduster Impact	B33	19713	MC6S
A21	19717	Countersunk screw	B34	19723	Plastic washer Impact
A22	BKD12	Rubbersteel washer	B35	2043	Manometer 23mm impact
A23	19659	Bottle adapter impact	C1	19604	Hammerseat
A24	19694	Brass adapter impact	C2	19741	Grub screw
A25	BK10Z	O-ring	C3	BK23	O-ring
A26	19689	Trigger guard impact	C4	19647	Valverod
A27		Washer	C5	19624	Hammer Impact
A28	2043	Manometer 23mm impact	C6	19623	Spring guide Impact
A29	16303	Quick connector male	C7	11500	Hammerspring v2
A30	BK81Z	O-ring	C8	19609	Spring holder Impact
A31	BK23	O-ring	C9	19683	Grub screw
A32	19005	Backvalve	C10	19602	Hammer adjuster
A33	19479	MC6S	C11	19715	MC6S
A34	2504	Countersunk screw	C12	2504	Countersunk
A35	19610	Safety Impact	C13	19693	Impact sprintholder
A36	19736	Delrin bushing 5,3	C14	19712	Countersunk screw
A37	19715	MC6S	C15	19608	Power adjuster Impact
A38	14500	MC6S	C16	11501	Spring
B1	19618	Impact Recoild-pad	C17	4066	Steel ball
B2	19728	Shoulderpad Adjuster screw	C18	11501	Spring
B3	19645	Left plate impact	C19	4066	Steel ball
B4	19646	Right plate impact	C20	19710	Houge rubber grip
B5	12610	MC6S	C21	19743	MC6S
B6	19606	Magazine holder Impact	C22	19636	Triggercatch Impact
B7	5110	Rubberball	C23	11504	Spring
B8	19620	Feeding pin impact 5,5	C24	19742	Grub screw
B9	19678	Grub screw	C25	11062	M5 secondstage std
B10	19614	Feedingpin holder	C26	2500	Grub screw
B11	19601	CPK 2h6x6	C27	19613	Trigger pin Impact
B12	19612	Feedingpin Guide	C28	11525	Triggerroll
B13	2505	Countersunk screw	C29	2504	Countersunk

Spare parts available at:
spares.bagnallandkirkwood.co.uk

For spare parts not listed please contact us using the reference codes above

