

Spare parts available at:
spares.bagnallandkirkwood.co.uk
For spare parts not listed please contact us using the reference codes above

NO	ART. NO	DESCRIPTION
1	2002	AIR CYLINDER [STANDARD]
2	2004	BARREL HOUSING
3	2010	HAMMERHOUSING COVER
4	2011	HAMMER HOUSING
5	2009	END PLUG
6	2012	MAIN VALVE HOUSING
7	2013	VIBRATION DAMPER
8	2008	FRONT PLUG
9	2014	MAIN VALVE LID
10	2015	BARREL HOLDER
11	FP3	FILL PROBE
12	2070	SIDEPLATE
13	2016	COCKING BOLT [BLACK]
14	2018	PRESSURE GAUGE SPACER
15	2019	TRIGGER BLOCK
16	2020	TRIGGER BLADE
17	2021	TRIGGER BASE
18	2022	MAIN VALVE PIN
19	2023	VALVE SEAT
20	2025	HAMMER FOOT
21	2026	HAMMER PIN
22	2027	INDEX LEVER
23	2028	INDEX LEVER CONNECTOR
24	2029	MAGAZINE STOP
25	2030	MUZZLE END CAP
26	2031	VALVESCREW
27	2032	COCKING BOLT SPACER
28	2033	TRIGGER CAP
29	2034	MAGAZINE PIN
30	2035	MAGAZINE PIN HANDLE

NO	ART. NO	DESCRIPTION
31	5000	INLET VALVE
32	2036	AIR TRANSFER PORT 4.1
33	2038	HAMMER SPACER
34	2040	PLASTIC VALVE SEAL
35	2039	BRASS SPACER 6,6
36	2041	VALVE SEAL HOLDER
37	2044	BARREL .22
38	2047	BARREL .177
39	2050	MAGAZINE .22
40	2053	MAGAZINE .177
41	2056	BRASS BARREL INLET .22
42	2057	BRASS BARREL INLET .177
43	2058	PELLET PROD .22
44	2059	PELLET PROD .177
45	2042	PLASTIC WASHER
46	5003	PLASTIC WASHER
47	2043	PRESSURE GAUGE
48	2531	RUBBER BALL
49	2517	PIVOT PIN
50	2518	PIVOT PIN
51	2524	SPRING
52	2525	SPRING
53	2519	SPRING
54	2522	SPRING
55	2523	HAMMERSPRING [HARD]
56	2520	SPRING
57	BK5	O-RING
58	BK14	O-RING
59	BK38	O-RING .177 (4,5mm)
60	BK48	O-RING

NO	ART. NO	DESCRIPTION
61	BK51	O-RING
62	BK89	O-RING
63	BK112	O-RING
64	2500	SCREW
65	2501	SCREW
66	2502	SCREW
67	2503	SCREW
68	2504	SCREW
69	2508	SCREW
70	2505	SCREW
71	2506	SCREW
72	12610	SCREW
73	2532	SCREW
74	5201	SCREW
75	2509	SCREW
76	2512	SCREW
77	2003	AIR CYLINDER [CARBINE]
78	2045	BARREL .22 CARBINE
79	2507	HAMMERSPRING [SOFT]
80	5005	PLASTIC WASHER 2MM
81	2071	SIDEPLATE
82	2017	COCKING BOLT [BRASS]
83	2081	AIR TRANSFER PORT 2.0
84	2037	AIR TRANSFER PORT 1.5
85	11508	SCREW
86	2063	TRIGGER SPACER
87	BK51	O-RING .22 (5,5mm)

Spare parts available at:
spares.bagnallandkirkwood.co.uk
For spare parts not listed please contact us using the reference codes above