



Spare parts available at:  
[spares.bagnallandkirkwood.co.uk](http://spares.bagnallandkirkwood.co.uk)  
 For spare parts not listed please contact us using the reference codes above



Partslist FX Crown

Location	Article number	Description	Location	Article number	Description
A1-Walnut	19940	Crown Walnut Stock	D22	19329	Checkvalve rod "gold"
A1-Gray	19943	Crown Laminate Gray Stock	D23	BK14	O-ring
A1-Green	19941	Crown Laminate Green Stock	D24	BK91	O-ring
A1-Blue	19942	Crown Laminate Blue Stock	D25	19939	quickconnector Crown
A2	19901	Breechblock Crown	D26	BK33	O-ring
A3-4,5 & 5,5	19142	Shroud tube 28x447mm	D27	19696	Regulator Kolv
A3-6,35 & 7,62	19975	Shroud tube 28x562mm	D28	BK33	O-ring
A4	5532	Carbon Fibre bottle Complete	D29	BK76Z	O-ring
B1	BK97.2	O-ring	D30	BK69	O-ring
B2	BK97.2	O-ring	D31	19697	Regulator hus
B3	19925	Shroud-cone Crown	D32	BK69	O-ring
B4	11509	CPK 3h6x10	D33	19695	Regulator Screw
B5	11201	Grubscrw	D34	BKD12	Rubbersteel washer
B6	19926	Shroudstop Crown	D35	19659	Bottle adapter
B7	19911	Shroud compensator 5,5	D36	19905	Valvehouse crown
B7	19912	Shroud compensator 6,35	D37	BK89	O-ring
B7	19913	Shroud compensator 7,62	D38	BK14	O-ring
B8	19951	O-ring	D39	19038	Springseat
B9- 4,5 & 5,5	19654	Muzzle 4,5 & 5,5	D40	2525	Spring
B9-6,35	19655	Muzzle 6,35	D41	19929	Valvepin Crown CPL
B9-7,62	19656	Muzzle 7,62	D42	19217	Valveseat CPL
C1-4,5 / .177	BK38	O-ring	D43	16104	Countersunk screw
C1-5,5 / .22	BK55	O-ring	D44	19915	Power adjuster house
C1-6,35 / .25	BK62	O-ring	D45	19923	Poweradjuster outer crown
C1-7,62 / .30	BK65.7	O-ring	D46	BK87.9Z	O-ring
C2	19703	O-ring	D47	19922	Power adjuster inner Crown
C3	19628	Barrel inlet 4,5	D48	BK59.5	O-ring
C3	19629	Barrel inlet 5,5	D49	4066	Steel Ball
C3	19670	Barrel inlet 6,35	D50	11501	Spring
C3	19671	Barrel inlet 7,62	D51	2637	Grub screw
D1	2508	Countersunk screw	D52	2637	Grub screw
D2	19908	Power adjuster Crown	D53	2637	Grub screw
D3	19902	Springholder Crown	D54	19846	Grub screw
D4	19909	Hammer adjuster	D55	19955	Grub screw
D5	19683	Grubscree	E1	12035	Grub screw
D6	11500	Hammerspring v2	E2	19136	Triggerblade
D7	19039	Hammer v7	E3	19137	Triggerpin
D8	11501	Spring	E4	19178	MC6s
D9	4066	Steelball	E5	11015	Second stage
D10	11501	Spring	E6	19678	Grub screw
D11	4066	Steelball	E7	11544	1st stage spring
D12	19907	Safety Crown	E8	19934	Trigger sear Crown
D13	19906	safetyflag Crown	E9	11525	Trigger roll
D14	11546	MC6S M3x14	E10	19927	Screw trigger roll
D15	1501	CPK	F1	19479	MC6S
D16	19026	CPK	F2	19611	Reloading handle
D17	11508	Grub screw	F3	19638	Reloading arm
D18	19904	Plugg	F4	19026	CPK
D19	BK99Z	O-ring	F5	19935	Linkage Crown
D20	19723	Plastic washer	F6	19601	CPK
D21	11505	Manometer	F7	11544	Spring

Spare parts available at:

[spares.bagnallandkirkwood.co.uk](http://spares.bagnallandkirkwood.co.uk)

For spare parts not listed please contact us using the reference codes above

F8	11509	CPK	F13-7,62	19920	Feedingpin Crown 7,62
F9	19921	Carrier			
F10	11503	Spring			
F11	4066	Steelball			
F12	19914	Feedingpin Screw			
F13-4,5	19917	Feedingpin 4,5 Crown			
F13-5,5	19918	Feedingpin 5,5 Crown			
F13-6,35	19919	Feedingpin 6,35 Crown			

Spare parts available at:  
**[spares.bagnallandkirkwood.co.uk](http://spares.bagnallandkirkwood.co.uk)**  
For spare parts not listed please contact us using the reference codes above