





5.8172 UX Morph Pistol



1-32	Internal Barrel Adopter	1	Ext. Barrel Combination	
1-33	Barrel Connector(R)	1	1-29 Ext. Barrel(L)	1
1-35	Slide Cover	1	1-30 Ext. Barrel(R)	1
1-36	Grip Parts	1	1-31 Barrel Fixing Parts	1
1-37	Front Sight	1	1-49 Silencer Spring	1
1-38	Sight	1	1-52 Internal Ext. Barrel	1
1-39	U-Type Fiber Optic	1	1-53 Barrel Fixing Parts	1
1-40	Front Fiber Optic	1	1-54 Ext. Outer Barrel	1
1-41	Axis	3	1-55 Washer	1
1-42	Screw	1	1-56 C Washer	1
1-44	Spring Bar	2	1-57 O-ring	1
1-45	Screw	6	1-58 O-ring	1
1-46	Screw	2	1-60 Screw	1
1-47	Screw	2	1-61 Ext. Barrel Weight	1
1-48	Screw	1	Front Stock Combination	
1-50	Hammer Stopper Spring	1	1-14 Front Stock(L)	1
1-51	Mag. Spring	1	1-15 Front Stock(R)	1
1-59	O-ring	1	1-16 Front Sight Black	1
1-12	Fixing Guide	1	3-06 Internal Barrel	1
1-13	BB Housing	1	7-07 Valve	1
1-17	Barrel Connector(L)	1	3-08 Screw	2
1-18	Trigger	1	7-08 Copper Ring	1
1-19	Recoil Spring	1	3-09 C Washer	1
1-20	BB Stopper Spring	1	7-09 Filter	1
1-21	Fixing Guide Spring	1	3-11 Screw	1
1-22	Trigger Spring	1	7-10 Piercer	1
1-23	Safety Spring	1	7-11 Fixing Ring	1
1-25	Attacked Block	1	7-12 O-ring	1
1-26	BB Stopper	1	7-13 Axis	1
1-27	Butt(L)	1	7-14 Washer	1
1-28	Butt(R)	1	7-15 Screw	1
1-29	Butt Bottom	1	7-16 Valve Spring	1
1-30	Ext. Barrel(L)	1	8A Knob Combination	1
1-31	Barrel Fixing Parts	1		
1-34	Butt Bottom	1		
1-38	Sight	1		
1-41	Axis	3		
1-42	Screw	1		
1-44	Spring Bar	2		
1-45	Screw	6		
1-46	Screw	2		
1-47	Screw	2		
1-48	Screw	1		
1-50	Hammer Stopper Spring	1		
1-51	Mag. Spring	1		
1-59	O-ring	1		
1-12	Fixing Guide	1		
1-13	BB Housing	1		
1-17	Barrel Connector(L)	1		
1-18	Trigger	1		
1-19	Recoil Spring	1		
1-20	BB Stopper Spring	1		
1-21	Fixing Guide Spring	1		
1-22	Trigger Spring	1		
1-23	Safety Spring	1		
1-25	Attacked Block	1		
1-26	BB Stopper	1		
1-27	Butt(L)	1		
1-28	Butt(R)	1		
1-29	Butt Bottom	1		
1-30	Ext. Barrel(L)	1		
1-31	Barrel Fixing Parts	1		
1-34	Butt Bottom	1		
1-38	Sight	1		
1-41	Axis	3		
1-42	Screw	1		
1-44	Spring Bar	2		
1-45	Screw	6		
1-46	Screw	2		
1-47	Screw	2		
1-48	Screw	1		
1-50	Hammer Stopper Spring	1		
1-51	Mag. Spring	1		
1-59	O-ring	1		
1-12	Fixing Guide	1		
1-13	BB Housing	1		
1-17	Barrel Connector(L)	1		
1-18	Trigger	1		
1-19	Recoil Spring	1		
1-20	BB Stopper Spring	1		
1-21	Fixing Guide Spring	1		
1-22	Trigger Spring	1		
1-23	Safety Spring	1		
1-25	Attacked Block	1		
1-26	BB Stopper	1		
1-27	Butt(L)	1		
1-28	Butt(R)	1		
1-29	Butt Bottom	1		
1-30	Ext. Barrel(L)	1		
1-31	Barrel Fixing Parts	1		
1-34	Butt Bottom	1		
1-38	Sight	1		
1-41	Axis	3		
1-42	Screw	1		
1-44	Spring Bar	2		
1-45	Screw	6		
1-46	Screw	2		
1-47	Screw	2		
1-48	Screw	1		
1-50	Hammer Stopper Spring	1		
1-51	Mag. Spring	1		
1-59	O-ring	1		

1-01	Frame(L)	1	1-12	Fixing Guide	1	1-40	Front Fiber Optic	1
1-02	Frame(R)	1	1-13	BB Housing	1	1-41	Axis	3
1-03	Built-in Mag. Body	1	1-17	Barrel Connector(L)	1	1-42	Screw	1
1-04	Built-in Mag. Cover	1	1-18	Trigger	1	1-44	Spring Bar	2
1-05	BB Follower	1	1-19	Recoil Spring	1	1-45	Screw	6
1-06	BB Follower Parts	1	1-20	BB Stopper Spring	1	1-46	Screw	2
1-07	Back Cover	1	1-21	Fixing Guide Spring	1	1-47	Screw	2
1-08	Safety	1	1-22	Trigger Spring	1	1-48	Screw	1
1-09	Safety Parts	1	1-23	Safety Spring	1	1-50	Hammer Stopper Spring	1
1-10	Safety Spring Seat	1	1-25	Attacked Block	1	1-51	Mag. Spring	1
1-11	Recoil Spring Stopper	1	1-26	BB Stopper	1	1-59	O-ring	1