



- 1- MODERATOR SOCKET
- 2- MODERATOR FRONT COVER
- 3- BARREL COVER
- 4- MODERATOR SPRING
- 5- BARREL COVER O-RING
- 6- BARREL SHROUD
- 7- MODERATOR BACK COVER
- 8- MODERATOR BACK COVER SETS
- 9- LEVEL SCALE
- 10- TOP COVER SCREW
- 11- TOP COVER
- 12- NEEDLE CONTRA PIN
- 13- NEEDLE CONTRA SPRING
- 14- NEEDLE CONTRA SETS
- 15- TOP COVER CENTERING PIN

%! <5A A 9F I DD9F D-B
 %! <5A A 9F
 %! DC K 9F 58>I GHA 9BHJ 5@ 9G9H
 %! DC K 9F 58>I GHA 9BHJ 5@ 9
 GDF-B:
 &S! DC K 9F 58>I GHA 9BHJ 5@ 9DB
 &A 5; 5NB9
 && 65FF9@; L-B; G9HG
 &! 65FF9@
 &! 65FF9@C I HF C IF-B;
 &! 65FF9@BG89C IF-B;
 &! 7 C J 9F-B; <5B8@G7 F9K
 &! 7 C J 9F-B; 5FA 6I G-
 &! @J 9@G7 F9K
 &! D-7 5HBBM
 &! G5; 9HMD-B

*! 7 C J 9F-B; K F 9 695F-B;
 (+! 7 C J 9F-B; K F 9
)! @J 9@
 (-! 7 C J 9F-B; G<5; H
)! @J 9@695F-B;
)! HF 5J 9@B; D-7 5HBBM G7 F9K
 &! HF#; 9F K F 9
)! 7 C @K F 9
)! 7 C J 9F-B; 5FA
)! @J 9@
)! A 5BCA 9HF
)! A 5BCA 9HF C IF-B;
)! G5; 9HMG5A D
)! G5; 9HMG5A K
 *! HF#; 9F; FC I D 7 C J 9F
 *! HF#; 9F; FC I D 7 C J 9F G7 F9K

*! HF#; 9F; FC I D 7 C J 9F
 *! A 5; 5NB 9G C D9F
 *! HF#; 9F D-B
 *! (I G F J @ C F
 *)! <5A A 9F <C @B 9F GDF-B;
 *)! <5A A 9F <C @B 9F
 *)! B 998 @ 8F @ 9F
 *)! DC K 9F 58>I GHA 9BHJ 5@ 9
 *)! <5A A 9F <C @B 9F GDF-B;
 +! <5A A 9F <C @B 9F 6F 57 ? 9H
 +! <5A A 9F GDF-B;
 +! <5A A 9F GDF-B;
 +! <5A A 9F
 +! 7 5G9
 +! <5A A 9F 8F @ 9F D-B

+! <5A A 9F D-B
 +! J 5 @ 9 6C 8M C IF-B;
 +! J 5 @ 9 6C 8M
 +! J 5 @ 9 6C 8M; L-B; G9HG
 .! \$! 15 ? 9 J 5 @ 9 6C 8M C IF-B;
 %! C IF-B;
 &! VALVE
 .! GDF-B;
 .! (I 6@;
 .! (I 6@; 7 C J 9F
 .! *! 6@; H-7 ? C IF-B;
 .! 6@ H-B C IF-B;
 .! -!; @B; J 5 @ 9G9G
 -! \$! FILLING J 5 @ 9GDF-B;

91- FILLING VALVE
 92- FILLING VALVE O-RING
 93-TUBE FRONT BLOG
 94-RELEASE O-RING
 95-DISCHARGE
 96-TUBE FRONT COVER
 97-UPPER BODY SIDE SCREW
 98-UPPER BODY
 99-SHEET COVER
 100-BRANDED SHEET COVER
 101-UPPER BODY UPPER SCREW
 102-BOTTOM BODY
 103-BOTTOM BODY FIXING SCREW
 104-BOTTOM BODY CABLE COVER
 105-BASE RUBBER FIXING SCREW
 106-BASE RUBBER EXTENSION
 ADJUSTMENT SCREW
 107-FIXED PLASTIC
 108-BASE RUBBER LATCH SPRING
 109-BASE RUBBER CLAMP
 110-EXTENSION ADJUSTMENT PLASTIC
 111-BASE TIRE
 112-POWER ADJUSTMENT VALVE O-RING